# 電腦視覺原理及應用簡介

Lab1
Read/Write Images and Videos

#### Course Information

- Lecture: Thursday 10:00~12:00
- Lab: 9 times (6:00pm~9:00pm)
- Reference books:
  - R. C. Gonzalez, R. E. Woods, Digital Image Processing, Prentice-Hall
  - Shapiro and Stockman, Computer Vision, Prentice-Hall
- TA:
  - 陳思穎 sihying1996@gmail.com
  - 姚雅馨 q121000777@gmail.com
  - 吳泰德 <u>f0966066981@gmail.com</u>(main contact)
  - 黄宇睿 alucard6686@gmail.com

#### Lab Sessions

- Upload your file including code and result image after your work is checked by TA.
- If you can not finish your work in time, <u>let the TA know your</u> name and make sure you have attended the lab session.
- If you cannot finish the lab in time (before 9:00pm), we accept make-up results within one week and you can get 70% score.
  - Make-up time :
    - Tuseday 12:00 13:00, at A308
- We do not accept make-up demos if you did not attend the lab sessions.

## Development Environment

- OS: Windows 10
- Programming Language: Python3.5
- Library : OpenCV
  - How to install opency library for python?
    - Open Command(or a PowerShell) window
    - Insert the command "pip install opency-python"

# Intro to OpenCV

- OpenCV is an image processing library
- Available on Mac, Windows, Linux
- Works in C, C++, and Python
- Open Source and free.
- Easy to use and install

# **Images**

# How to Read/Write image

#### Read

- cv2.imread(file\_Name, flag)
  - filename: the image should be in the working directory or a full path of image should be given
  - flag: the way image should be read, including 'cv2.IMREAD\_COLORD', 'cv2.IMREAD\_GRAYSCALE', 'cv2.IMREAD\_UNCHANGED'
- Display
  - cv2.imshow('window\_Name', image)
- Write
  - cv2.imwrite('messigray.png',image)

#### Demo

RGB to Grayscale



# How to convert RGB to Grayscale?

- Import main library
- Read the image
- Do the processing
- Show the image
- Close and exit

#### Cont.

```
### Import library ###
    import cv2
     import numpy as np
     ### Read the image ###
 6
     img = cv2.imread('littleMINI.jpg')
    ### Do the processing ###
     row, cols, channels = img.shape
10
     b, g, r = cv2.split(img)
     gray = 0.114 * b + 0.587 * g + 0.299 * r
11
12
     gray = gray.astype(np.uint8)
13
14
     ### Show the image ###
15
     cv2.imshow("gray", gray)
16
     cv2.imshow('image',img)
17
18
    ### Close and exit ###
19
     cv2.waitKey(0)
20
     cv2.destroyAllWindows()
```

# **Videoes**

# How to Read/Display video

```
### imoprt library ###
     import numpy as np
     import cv2
 4
     ### Capture from camera or Read an video ###
 6
     cap = cv2.VideoCapture('CloudFormationVideo.avi')
     ### Display the frame ###
     while(cap.isOpened()):
 9
10
         ret, frame = cap.read()
11
         ### Do the processing (convert RGB to grayscale)###
         gray = cv2.cvtColor(frame, cv2.COLOR BGR2GRAY)
12
13
         cv2.imshow('frame',gray)
14
         if cv2.waitKey(1) & 0xFF == ord('q'):
15
             break
16
17
     ### Close and Exit ###
18
     cap.release()
19
     cv2.destroyAllWindows()
```

# Assignment

- 請至LMS下載影片
- 利用 openCV 讀取影片,並將影片轉為灰階
- 在影片播放時,可以有以下四個功能:
  - 1. 按 r 的時候,可以將此刻的影片存成紅色圖片
  - 2. 按 g 的時候,可以將此刻的影片存成綠色圖片
  - 3. 按 b 的時候,可以將此刻的影片存成藍色圖片
  - 4. 按 q 的時候,關閉影片

p.s.播放影片時的window name 和存圖片的檔名請加上自己的姓名和學號 e.g. 107522091\_陳思穎\_Capture\_r.png

## Demo



